



# QUICK START GUIDE

WHEN POWER AND GPS LIGHTS ARE ON, YOU'RE READY:

- \* Your Transmitter should be Pre Programmed for your time zone.

---

- \* If you see a different time zone, please follow Self Programming steps to change to your time zone.
- \* If your area doesn't have Daylight Savings Time, please follow steps to cancel DST.
- \* IF YOU DO NOT GET A GREEN LIGHT FROM THE GPS SIGNAL. YOU MAY INPUT THE TIME MANUALLY. THIS WILL CANCEL THE GPS ANTENNA AND INDICATE THE TIME YOU INPUT.

SELF PROGRAMMING STEPS:

1: Press and Hold Mode Button.

\* CHANNEL SELECT

A: Press Set to choose a Channel ( 00-09 )

2: PRESS MODE.

\*UTC OFFSET

A: Press Set to Choose Time Zone

3: PRESS MODE.

\*FORMAT

A: Press Set to Choose 12 or 24 Hour Clock

4: PRESS MODE.

\*DAYLIGHT SAVINGS TIME

A: Press Set to Choose Yes / No

5: PRESS MODE.

\* TIME

A: No ( IF YES PRESS SET )

PRESS MODE.  
\*YEAR  
A: Press Set To Choose Year

PRESS MODE.  
\*MONTH  
A: Press Set to Choose Month

PRESS MODE.  
\*DAY  
A: Press Set to Choose Day

PRESS MODE.  
\*HOUR  
A: Press Set to Choose Hour

PRESS MODE.  
\*MINUTE  
A: Press Set to Choose Minute

## TRANSMITTER PROGRAMING

